

NUC BOX-N97/D5

Version 1.0

Published December, 2025

Copyright©2025 ASRock Industrial Inc. All rights reserved.

Copyright Notice:

No part of this documentation may be reproduced, transcribed, transmitted, or translated in any language, in any form or by any means, except duplication of documentation by the purchaser for backup purpose, without written consent of ASRock Industrial Inc.

Products and corporate names appearing in this documentation may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

Disclaimer:

Specifications and information contained in this documentation are furnished for informational use only and subject to change without notice, and should not be constructed as a commitment by ASRock Industrial. ASRock Industrial assumes no responsibility for any errors or omissions that may appear in this documentation.

To the extent permitted by law, with respect to the contents of this documentation, ASRock Industrial does not provide warranty of any kind, either expressed or implied, including but not limited to the implied warranties or conditions of merchantability or fitness for a particular purpose.

In no event shall ASRock Industrial, its directors, officers, employees, or agents be liable for any indirect, special, incidental, or consequential damages (including damages for loss of profits, loss of business, loss of data, interruption of business and the like), even if ASRock Industrial has been advised of the possibility of such damages arising from any defect or error in the documentation or product.



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

CALIFORNIA, USA ONLY

The Lithium battery adopted on this motherboard contains Perchlorate, a toxic substance controlled in Perchlorate Best Management Practices (BMP) regulations passed by the California Legislature. When you discard the Lithium battery in California, USA, please follow the related regulations in advance.

"Perchlorate Material-special handling may apply, see www.dtsc.ca.gov/hazardouswaste/perchlorate"

AUSTRALIA ONLY

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage caused by our goods. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. If you require assistance please call ASRockInd Tel : +886-2-28965588 ext.123 (Standard International call charges apply)

Replaceable batteries

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

This product is intended to be supplied by a Listed Power Adapter or DC power source marked "L.P.S." (or "Limited Power Source"), rated 19 Vdc, 3.42 A minimum, Tma = 40 degree C minimum.


All interior servicing is to be performed by qualified skilled personnel only.



CAUTION (or Warning)

Hot surface
Do not touch

The equipment intended only for use in a Restricted Access Area.



VESA Mount: M4x6mm Screws *(for securing the VESA bracket to the monitor)*

This product should be connected by means of a power cord to a socket-outlet with earthing connection.



The terms HDMI® and HDMI High-Definition Multimedia Interface, and the HDMI logo are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.



ASRockInd follows the green design concept to design and manufacture our products, and makes sure that each stage of the product life cycle of ASRockInd product is in line with global environmental regulations. In addition, ASRockInd disclose the relevant information based on regulation requirements.



DO NOT throw the motherboard in municipal waste. This product has been designed to enable proper reuse of parts and recycling. This symbol of the crossed out wheeled bin indicates that the product (electrical and electronic equipment) should not be placed in municipal waste. Check local regulations for disposal of electronic products.

Contact Information

If you need to contact ASRock Industrial or want to know more about ASRock Industrial, you're welcome to visit ASRock Industrial's website at <https://www.asrockind.com>; or you may contact your dealer for further information.

ASRock Industrial Incorporation

Email: Info_ipc@asrockind.com

Contents

Chapter 1 Introduction	1
1.1 Package Contents	1
1.2 Product Specifications	2
1.3 Block Diagram	4
Chapter 2 Product Overview	5
2.1 Front View	5
2.2 Rear View	6
2.3 Inside View	7
Chapter 3 Hardware Installation	8
3.1 How to Remove the Bottom Case	8
3.2 How to Install the WiFi Module	9
3.3 How to Install the M.2 SSD (Type 2280)	10
3.4 How to Remove the M.2 SSD (Type 2280) and the Bracket	11
3.5 How to Install the M.2 SSD (Type 2260)	12
3.6 How to Install the Memory Modules (DDR5)	13
3.7 How to Install the 2.5-inch Hard Drive	14
3.8 How to Install the VESA Bracket	16
3.9 Positions of the NUC BOX-N97/D5	17
Chapter 4 Motherboard	18
4.1 Motherboard Layout	18
4.2 Jumpers Setup	20
4.3 Onboard Headers and Connectors	21

4.4	Expansion Slots (M.2 Slots)	24
-----	-----------------------------	----

Chapter 5	UEFI Setup Utility	25
------------------	---------------------------	-----------

5.1	Introduction	25
-----	--------------	----

5.1.1	Entering BIOS Setup	25
-------	---------------------	----

5.1.2	UEFI Menu Bar	26
-------	---------------	----

5.1.3	Navigation Keys	27
-------	-----------------	----

5.2	Main Screen	28
-----	-------------	----

5.3	Advanced Screen	29
-----	-----------------	----

5.3.1	CPU Configuration	30
-------	-------------------	----

5.3.2	Chipset Configuration	33
-------	-----------------------	----

5.3.3	Storage Configuration	35
-------	-----------------------	----

5.3.4	Super IO Configuration	37
-------	------------------------	----

5.3.5	ACPI Configuration	38
-------	--------------------	----

5.3.6	USB Configuration	39
-------	-------------------	----

5.3.7	Power Configuration	40
-------	---------------------	----

5.3.8	Trusted Computing	41
-------	-------------------	----

5.4	Hardware Health Event Monitoring Screen	43
-----	---	----

5.5	Security Screen	44
-----	-----------------	----

5.6	Boot Screen	45
-----	-------------	----

5.7	Exit Screen	46
-----	-------------	----

Chapter 6	Software Support	47
------------------	-------------------------	-----------

6.1	Install Operating System	47
-----	--------------------------	----

Chapter 1 Introduction



Because the hardware specifications might be updated, the content of this documentation will be subject to change without notice.

1.1 Package Contents

- 1 x NUC BOX-N97/D5
- 1 x 19V/65W power adapter
- 1 x VESA mount bracket
- 1 x Quick Installation Guide



The barebone system does not include memory, hard drive and M.2 SSD.



If any items are missing or appear damaged, contact your authorized dealer.

1.2 Product Specifications

Processor System

CPU	Intel® Alder Lake-N Processors N97
Chipset	MCP
BIOS	AMI SPI 256 Mbit

Memory

Technology	Single Channel DDR5 4800 MHz
Capacity	32GB
Socket	1 x 262-pin SO-DIMM

Graphics

Controller	Intel® UHD Graphics
HDMI	HDMI 2.0b Max resolution up to 4096x2160@60Hz
DisplayPort	DisplayPort 1.4a, DP++ Max resolution up to 4096x2160@60Hz
MultiDisplay	Triple-Display (Included 2 outputs from Type-C)

Expansion Slot

M.2/ WLAN	1 x Wi-Fi 6E 802.11ax + BT 5.2
-----------	--------------------------------

Audio

Interface	Realtek ALC256, High Definition Audio
-----------	---------------------------------------

Ethernet

Controller/ Speed	LAN1: Realtek RTL8125BG with 10/100/1000/2500 Mbps LAN2: Realtek RTL8125BG with 10/100/1000/2500 Mbps
Connector	2 x RJ-45

Storage

M.2	1 x M.2 (KEY M, 2242/2260/2280) with PCIe Gen3 x1 and SATA3 for SSD *M.2 Key M 2280 (Supported by bracket)
SATA	1 x SATA3.0 (6.0 Gb/s)

Front I/O

USB	1 x USB 3.2 Gen2 (Type-A) 2 x USB 3.2 Gen2 (Type-C, Supports DP1.4a display output)
Audio	1 (headphone & microphone jack)

Rear I/O

HDMI	2 x HDMI 2.0b
Ethernet	2 x 2.5 Gigabit LAN
USB	2 x USB 3.2 Gen2 (Type-A)
DC Jack	1

Watchdog Timer

Output	From Super I/O to drag RESETCON#
Interval	256 Segments, 0, 1, 2, ...255sec

Power Requirements

Input PWR	9V~24V DC-In Jack
Power On	AT/ATX Supported - AT : Directly PWR on as power input ready - ATX : Press button to PWR on after power input ready

Environment

Operating Temp	0°C ~ 40°C
Storage Temp	-40° C ~ 85° C
Operating Humidity	5% ~ 90% (non-condensing)
Storage Humidity	5% ~ 90% (non-condensing)


Mechanical

Mounting	VESA mount
Dimensions (L x W x H)	117.5 x 110.0 x 47.85mm (4.63" x 4.33" x 1.88")
Weight	Net Weight: 1.0Kg

Others

OS Support	Windows 10/11
TPM	TPM 2.0 onboard IC
Certifications	CE, FCC
Packing List	1 x 19V/65W Power Adapter 1 x VESA mount bracket


1.3 Block Diagram



Chapter 2 Product Overview


This chapter provides diagrams showing the location of important components of the NUC BOX-N97/D5.

2.1 Front View




No.	Description
1	Audio (Mic-in, Line-out)
2	2 x USB 3.2 Gen2 (Type-C, supports DP1.4a display output)
3	USB 3.2 Gen2 (Type-A)

2.2 Rear View




No.	Description
1	DC-IN
2	2 x HDMI
3	2 x RJ-45 (2.5G)*
4	2 x USB 3.2 Gen2 Port

* There are two LEDs on the LAN port. Please refer to the table below for the LAN port LED indications.



Activity / Link LED		Speed LED	
Status	Description	Status	Description
Off	No Link	Off	10Mbps connection
Blinking	Data Activity	Orange	100Mbps/1Gbps connection
On	Link	Green	2.5Gbps connection

2.3 Inside View



No.	Description
1	M.2 Slot (Key E, 2230 PCIe Gen3 x1, USB 2.0 and CNVio/CNVio2 for Wireless)
2	M.2 Slot (Key M, 2242/2260/2280 with PCIe Gen3 x1 and SATA3 for SSD)
3	SATA 3.0 Connector
4	SO-DIMM Slot




SO-DIMM memory, hard drive and mSATA SSD are not included with this system.

Chapter 3 Hardware Installation

This chapter helps you install or remove important components.


3.1 How to Remove the Bottom Case

1. Remove the four screws on the bottom case.
2. Then lift up and remove the bottom case.




3.2 How to Install the WiFi Module


1. Locate the WiFi Module slot on the motherboard.



2. Carefully insert the WiFi Module into the slot at a 30-degree angle.




3. Tighten the screw to secure the WiFi Module to the motherboard.




3.3 How to Install the M.2 SSD (Type 2280)

1. Locate the M.2 slot on the motherboard.



2. Carefully insert the M.2 SSD (Type 2280) into the slot at a 30-degree angle.




3. Tighten the screw to secure the M.2 SSD (Type 2280) to the motherboard.




3.4 How to Remove the M.2 SSD (Type 2280) and the Bracket

1. Release the screw and carefully remove the M.2 SSD (Type 2280).




2. Release the screw and remove the bracket from the motherboard.




3.5 How to Install the M.2 SSD (Type 2260)


1. Locate the M.2 slot on the motherboard. Install the standoff.



2. Carefully insert the M.2 SSD (Type 2260) into the slot at a 30-degree angle.



3. Tighten the screw to secure the M.2 SSD (Type 2260) to the motherboard.



3.6 How to Install the Memory Modules (DDR5)




The NUC BOX-N97/D5 requires DDR5 SO-DIMM (1.2V).




The SO-DIMM only fits in one correct orientation. It will cause permanent damage to the motherboard and the DIMM if you force the DIMM into the slot at incorrect orientation.

1. Carefully insert the SO-DIMM memory module into the slot at a 30-degree angle.




2. Push down until the module snaps into place.




3.7 How to Install the 2.5-inch Hard Drive


1. Remove the four screws on the bottom case. Then lift up and remove the bottom case.




2. Attach the HDD to the hard drive mounting bracket and secure it using the four screws. Then connect the SATA Data and Power Cable to the HDD.




3. Attach the HDD assembly to the bottom case and secure it using the four screws.



4. Connect the SATA Cable to the connector.



5. Then reinstall the bottom case.




VIDEO TUTORIAL

Scan the QR code to watch the step-by-step video tutorial on how to install the hard disk drive on the NUC BOX-N97/D5.


3.8 How to Install the VESA Bracket

1. Attach the two screws to the base of the NUC BOX-N97/D5.




2. Attach the VESA Bracket to the rear of a compatible display using the four screws.

*Choose mounting holes depending on the mounting hole pattern of your LCD screen (75 mm × 75 mm or 100 mm × 100 mm).




3. Mount the NUC BOX-N97/D5 by sliding it into place.



3.9 Positions of the NUC BOX-N97/D5


The NUC BOX-N97/D5 can be placed in vertical or horizontal position.



Horizontal Position



Vertical Position




VESA-mounted




Please note that keeping the NUC BOX-N97/D5 in a vertical position will ensure better cooling performance.

Chapter 4 Motherboard

4.1 Motherboard Layout



- 1 : M.2 Key-M Socket (M2_M1)
- 2 : M.2 Key-E Socket (M2_E1)
- 3 : COM Port Header (COM1) (RS232/422/485)*
- 4 : USB 2.0 Header (USB2H_1_2)
- 5 : SATA Port (SATA3_0)
- 6 : JP1
- 7 : System Panel Header (PANEL1)
- 8 : 4-pin DC-in Wafer (DC_IN1) (BOM option)



Back Side :

9 : Power Button (PWR_BTN1)


10 : Fan Connector (FAN1)

11 : Battery Connector (BAT1)


12 : ESPI Connector (ESPI)

4.2 Jumpers Setup

The illustration shows how jumpers are setup. When the jumper cap is placed on pins, the jumper is “Short.” If no jumper cap is placed on pins, the jumper is “Open.” The illustration shows a 3-pin jumper whose pin1 and pin2 are “Short” when jumper cap is placed on these 2 pins.



JP1
(10-pin SATA3_0)
(see p. 18, No. 6)



Pin	Signal Name
1-2	SIO AT Mode (Default Open: SIO ATX Mode)
3-4	Auto Clear CMOS
4-6	Clear CMOS
5-7	DACC*
9	Case open
10	GND

*Auto clear CMOS when system boot improperly.


4.3 Onboard Headers and Connectors



Onboard headers and connectors are NOT jumpers. Do NOT place jumper caps over these headers and connectors. Placing jumper caps over the headers and connectors will cause permanent damage to the motherboard!

COM Port Header (RS-232/422/485)

(9-pin COM1)
(see p. 18, No. 3)



Pin	Signal Name	Signal Name	Pin
1	DDCD#1	RRXD1	2
3	TTXD1	DDTR#1	4
5	GND	DDSR#1	6
7	RRTS#1	CCTS#1	8
9	DUMMY		10




This motherboard supports RS232/422/485 on COM1 port. Please refer to the table below for the pin definition. In addition, COM1 port (RS232/422/485) can be adjusted in BIOS setup utility > Advanced Screen > Super IO Configuration. You may refer to our manual for details.

COM1 Port Pin Definition

Pin	RS232	RS422	RS485
1	DCD	TX-	RTX-
2	RXD	TX+	RTX+
3	TXD	RX+	NA
4	DTR	RX-	NA
5	GND	GND	GND
6	DSR	NA	NA
7	RTS	NA	NA
8	CTS	NA	NA
9	NA	NA	NA

USB 2.0 Header


(9-pin USB2H_1_2)
(see p. 18, No. 4)



Pin	Signal Name	Signal Name	Pin
1	USB_PWR	USB_PWR	2
3	USB_D-	USB_D-	4
5	USB_D-	USB_D+	6
7	GND	GND	8
9	DUMMY		10

The board provides one internal USB 2.0 header, which can support two USB 2.0 ports. The maximum current per port is 0.5A.


SATA Port
(20-pin SATA3_0)
(see p. 18, No. 5)



Pin	Signal Name
1	GND
2	SATA-A+
3	SATA-A-
4	GND
5	GND
6	SATA-B-
7	SATA-B+
8	GND
9	GND
10	GND
11	NC
12	+5V
13	+5V
14	+5V
15	+5V
16	+5V
17	NC
18	GND
19	GND
20	GND

The Serial ATA3 (SATA3) connector supports SATA data cables for internal storage devices.
The current SATA3 interface allows up to 6.0 Gb/s data transfer rate.

System Panel Header
(9-pin PANEL1)
(see p. 18, No. 7)



Pin	Signal Name	Signal Name	Pin
1	HDLED+	PLED+	2
3	HDLED-	PLED-	4
5	GND	PWRBTN#	6
7	RESET#	GND	8
9	+5VSB		10

This header accommodates several system front panel functions.



Connect the power switch, reset switch and system status indicator on the chassis to this header according to the pin assignments below. Note the positive and negative pins before connecting the cables.

PWRBTN (Power Switch):

Connect to the power switch on the chassis front panel. You may configure the way to turn off your system using the power switch.

RESET (Reset Switch):

Connect to the reset switch on the chassis front panel. Press the reset switch to restart the computer if the computer freezes and fails to perform a normal restart.

PLED (System Power LED):

Connect to the power status indicator on the chassis front panel. The LED is on when the system is operating. The LED keeps blinking when the system is in S3 sleep state. The LED is off when the system is in S4 sleep state or powered off (S5).

HDLED (Hard Drive Activity LED):

Connect to the hard drive activity LED on the chassis front panel. The LED is on when the hard drive is reading or writing data.

The front panel design may differ by chassis. A front panel module mainly consists of power switch, reset switch, power LED, hard drive activity LED, speaker and etc. When connecting your chassis front panel module to this header, make sure the wire assignments and the pin assignments are matched correctly.

4-pin DC-In Wafer (BOM option)

(4-pin DC-IN1)

(see p. 18, No. 8)



Pin	Signal Name
1	GND
2	DC Input
3	DC Input
4	GND

Back Side :

Power Button

(PWR_BTN1)

(see p. 19, No. 9)



Fan Connector

(4-pin FAN1)

(see p. 19, No. 10)



Pin	Signal Name
1	GND
2	+5V
3	FAN_SPEED
4	FAN_SPEED_CONTROL

Battery Connector

(BAT1)

(see p. 19, No. 11)



Pin	Signal Name
1	+BAT
2	GND

ESPI Header

(20-pin ESPI1)

(see p. 19, No. 12)



Pin	Signal Name
1	GND
2	ESPI_CLK
3	GND
4	ESPI_CS#
5	ESPI_RESET#
6	GND
7	+3V
8	GND
9	SMB_CLK
10	SMB_DATA
11	ESPI_IO0
12	ESPI_IO1
13	ESPI_IO2
14	ESPI_IO3
15	GND
16	+3VSB
17	Internal use
18	Internal use
19	ESPI_ALERT#
20	GND

4.4 Expansion Slots (M.2 Slots)

There are two M.2 sockets on this motherboard.

M.2 for SSD: 1 x M.2 (KEY M, 2242/2260/2280) with PCIe Gen3 x1 and SATA3 for SSD

*M.2 Key M 2280 (Supported by bracket)

M.2 for Wi-Fi: 1 x M.2 (Key E, 2230) with PCIe Gen3 x1, USB 2.0 and CNVio/
CNVio2 for Wireless

M.2 Key-M Socket
(M2_M1)

Pin	Signal	Signal	Pin
1	GND	+3.3V	2
3	GND	+3.3V	4
5	NA	NA	6
7	NA	NA	8
9	GND	SATA_LED	10
11	NA	+3.3V	12
13	NA	+3.3V	14
15	GND	+3.3V	16
17	NA	+3.3V	18
19	NA	NA	20
21	GND	NA	22
23	NA	NA	24
25	NA	NA	26
27	GND	NA	28
29	NA	NA	30
31	NA	NA	32
33	GND	NA	34
35	NA	NA	36
37	NA	NA	38
39	GND	SMB_CLK	40
41	PERn0/SATA-B+	SMB_DATA	42
43	PERp0/SATA-B-	NA	44
45	GND	NA	46
47	PETn0/SATA-A-	NA	48
49	PETp0/SATA-A+	PERST#	50
51	GND	CLKREQ#	52
53	PEFCLKn	NA	54
55	PEFCLKp	NA	56
57	GND	NA	58
67	NA	NA	68
69	PEDET	+3.3V	70
71	GND	+3.3V	72
73	GND	+3.3V	74
75	GND		

M.2 Key-E Socket
(M2_E1)

Pin	Signal	Signal	Pin
1	GND	+3.3V	2
3	USB_D+	+3.3V	4
5	USB_D-	NA	6
7	GND	NA	8
9	CNV_WGR_D1-	CNV_RF_RESET	10
11	CNV_WGR_D1+	NA	12
13	GND	MODEM_CLKREQ	14
15	CNV_WGR_D0-	NA	16
17	CNV_WGR_D0+	GND	18
19	GND	NA	20
21	CNV_WGR_CLK-	CNV_BRI_RSP	22
23	CNV_WGR_CLK+		
		CNV_BGL_DT	32
33	GND	CNV_RGI_RSP	34
35	PETp	CNV_BRI_DT	36
37	PETn	NA	38
39	GND	NA	40
41	PERp	NA	42
43	PERn	NA	44
45	GND	NA	46
47	PEFCLKp	NA	48
49	PEFCLKn	SUSCLK	50
51	GND	PERST0#	52
53	CLKREQ#	W_DISABLE1#	54
55	NA	W_DISABLE2#	56
57	GND	SMB_DATA	58
59	CNV_WT_D1-	SMB_CLK	60
61	CNV_WT_D1+	NA	62
63	GND	NA	64
65	CNV_WT_D0-	NA	66
67	CNV_WT_D0+	NA	68
69	GND	NA	70
71	CNV_WT_CLK-	+3.3V	72
73	CNV_WT_CLK+	+3.3V	74
75	GND		

Chapter 5 UEFI Setup Utility

5.1 Introduction

ASRock Industrial UEFI (Unified Extensible Firmware Interface) is a BIOS utility which offers tweak-friendly options in an advanced viewing interface. The UEFI system works with a USB mouse and offers users a faster, sleeker experience.

This BIOS utility can perform the Power-On Self-Test (POST) during system startup, record hardware parameters of the system, load operating system, and so on. The battery on the motherboard supplies the power needed to the CMOS when the system power is turned off, and the values configured in the UEFI utility are kept in the CMOS.

Please note that inadequate BIOS settings may cause system instability, malfunction or boot failure. We strongly recommend that you do not alter the UEFI default configurations or change the settings only with the assistance of a trained service person.

If the system becomes unstable or fails to boot after you change the setting, try to clear the CMOS values and reset the board to default values. See your motherboard manual for instructions.

5.1.1 Entering BIOS Setup

You may run the UEFI SETUP UTILITY by pressing <F2> or <Delete> right after you power on the computer; otherwise, the Power-On-Self-Test (POST) will continue with its test routines. If you wish to enter the UEFI SETUP UTILITY after POST, restart the system by pressing <Ctl> + <Alt> + <Delete>, or by pressing the reset button on the system chassis. You may also restart by turning the system off and then back on.

This setup guide explains how to use the UEFI SETUP UTILITY to configure all the supported system. The screenshots in this manual are for reference only. UEFI Settings and options may vary owing to different BIOS release versions or CPU installed. Please refer to the actual BIOS version of the motherboard you purchased for detailed screens, settings and options.

5.1.2 UEFI Menu Bar

The top of the screen has a menu bar with the following selections:

Main	For setting system time/date information
Advanced	For advanced system configurations
H/W Monitor	Displays current hardware status
Security	For security settings
Boot	For configuring boot settings and boot priority
Exit	Exit the current screen or the UEFI Setup Utility



Because the UEFI software is constantly being updated, the following UEFI setup screens and descriptions for reference purpose only, and may vary from the latest BIOS and do not exactly match what you see on your screen.

5.1.3 Navigation Keys


Use <←> key or <→> key to choose among the selections on the menu bar, and use <↑> key or <↓> key to move the cursor up or down to select items, then press <Enter> to get into the sub screen. You can also use the mouse to click your required item.

Please check the following table for the descriptions of each navigation key.

Navigation Key(s)	Description
+ / -	To change option for the selected items
<Tab>	Switch to next function
<PGUP>	Go to the previous page
<PGDN>	Go to the next page
<HOME>	Go to the top of the screen
<END>	Go to the bottom of the screen
<F1>	To display the General Help Screen
<F7>	Discard changes and exit the SETUP UTILITY
<F9>	Load optimal default values for all the settings
<F10>	Save changes and exit the SETUP UTILITY
<F12>	Print screen
<ESC>	Jump to the Exit Screen or exit the current screen

5.2 Main Screen


When you enter the UEFI SETUP UTILITY, the Main screen will appear and display the system overview.



Because the UEFI software is constantly being updated, the following UEFI setup screens and descriptions are for reference purpose only, and they may not exactly match what you see on your screen. Options may also vary depending on the features of your motherboard.

5.3 Advanced Screen

In this section, you may set the configurations for the following items: CPU Configuration, Chipset Configuration, Storage Configuration, Super IO Configuration, ACPI Configuration, USB Configuration, Power Configuration, and Trusted Computing.




Setting wrong values in this section may cause the system to malfunction.

Instant Flash

Instant Flash is a UEFI flash utility embedded in Flash ROM. This convenient UEFI update tool allows you to update system UEFI without entering operating systems first like Windows®. Just launch this tool and save the new UEFI file to your USB flash drive, floppy disk or hard drive, and then you can update your UEFI in only a few clicks without preparing an additional floppy diskette or other complicated flash utility. Please be noted that the USB flash drive or hard drive must use FAT32/16/12 file system. If you execute Instant Flash utility, the utility will show the UEFI files and their respective information. Select the proper UEFI file to update your UEFI, and reboot your system after UEFI update process completes.

5.3.1 CPU Configuration



Active Processor E-Cores

This allows you to select the number of E-Cores to enable in each processor package. NOTE: Number of P-Cores and E-Cores are looked at together. When both are {0,0}, Pcode will enable all cores.

CPU C States Support

This allows you to enable CPU C States Support for power saving. It is recommended to keep C3, C6 and C7 all enabled for better power saving.

Configuration options: [Enabled] [Disabled]

Enhanced Halt State (C1E)

The option allows you to enable Enhanced Halt State (C1E) for lower power consumption.

Configuration options: [Enabled] [Disabled]

Package C State Support

The option allows you to enable CPU, PCIe, Memory, Graphics C State Support for power saving.

Configuration options: [Auto] [Enabled] [Disabled]

CFG Lock

The option allows you to enable or disable the CFG Lock.

Configuration options: [Enabled] [Disabled]

Intel Virtualization Technology

Intel Virtualization Technology allows a platform to run multiple operating systems and applications in independent partitions, so that one computer system can function as multiple virtual systems.

Configuration options: [Enabled] [Disabled]

Intel SpeedStep Technology

Intel SpeedStep technology allows processors to switch between multiple frequencies and voltage points for better power saving and heat dissipation. CPU turbo ratio can be fixed when Intel SpeedStep Technology is set to [Disabled].

Configuration options: [Enabled] [Disabled].

If you install Windows® 10 and want to enable this function, please set this item to [Enabled]. This item will be hidden if the current CPU does not support Intel SpeedStep technology.



Please note that enabling this function may reduce CPU voltage and lead to system stability or compatibility issues with some power supplies. Please set this item to [Disabled] if above issues occur.

Intel Turbo Boost Technology

Intel Turbo Boost Technology enables the processor to run above its base operating frequency when the operating system requests the highest performance state. The default value is [Enabled].

Configuration options: [Enabled] [Disabled]

CPU Thermal Throttling

CPU Thermal Throttling allows you to enable CPU internal thermal control mechanisms to keep the CPU from overheating.

Configuration options: [Enabled] [Disabled]


Power Limit 1

"Power Limit 1 in Milli Watts. BIOS will round to the nearest 1/8W when programming. 0 = no custom override. For 12.50W, enter 12500. Overclocking SKU: Value must be between Max and Min Power Limits (specified by PACKAGE_POWER_SKU_MSR). Other SKUs: This value must be between Min Power Limit and Processor Base Power (TDP) Limit. If value is 0, BIOS will program Processor Base Power (TDP) value."

Power Limit 2

"Power Limit 2 value in Milli Watts. BIOS will round to the nearest 1/8W when programming. If the value is 0, BIOS will program this value as 1.25*Processor Base Power (TDP). For 12.50W, enter 12500. Processor applies control policies such that the package power does not exceed this limit."

5.3.2 Chipset Configuration



VT-d

Intel® Virtualization Technology for Directed I/O helps your virtual machine monitor better utilize hardware by improving application compatibility and reliability, and providing additional levels of manageability, security, isolation, and I/O performance.

Configuration options: [Enabled] [Disabled]

Share Memory

Share memory allows you to configure the size of memory that is allocated to the integrated graphics processor when the system boots up.

Configuration options: [Auto] [32M] [64M] [128M] [256M] [512M]

Options vary depending on the memory you use on your motherboard.

In-Band ECC Support

This allows you to enable or diable In-Band ECC.

Configuration options: [Enabled] [Disabled]

Render Standby

Power down the render unit when the GPU is idle for lower power consumption.

Configuration options: [Enabled] [Disabled]

Onboard LAN1

This allows you to enable or disable the Onboard LAN1 feature.

Configuration options: [Enabled] [Disabled]

Onboard LAN2

This allows you to enable or disable the Onboard LAN2 feature.

Configuration options: [Enabled] [Disabled]

Onboard HD Audio

This allows you to enable or disable the onboard HD audio.

Configuration options: [Enabled] [Disabled]

Deep S5

Mobile platforms support Deep S5 in DC only and desktop platforms support Deep S5 in AC only. The default value is [Disabled].

Configuration options: [Auto] [Disabled]

Restore on AC/Power Loss

The option allows you to select the power state after a power failure.


[Power Off] sets the power to remain off when the power recovers.

[Power On] sets the system to start to boot up when the power recovers.

EDID emulation

This allows you to enable or disable the EDID emulation feature.

5.3.3 Storage Configuration



SATA Controller(s)

The option allows you to enable or disable the SATA controllers.

Configuration options: [Enabled] [Disabled]

SATA Mode Selection

AHCI supports new features that improve performance.

Configuration option: [AHCI]



AHCI (Advanced Host Controller Interface) supports NCQ and other new features that will improve SATA disk performance.

Hybrid Storage Detection and Configuration Mode

The option allows you to select Hybrid Storage Detection and Configuration Mode.

Configuration options: [Dynamic Configuration for Hybrid Storage Enable] [Disabled]

SATA Aggressive Link Power Management

SATA Aggressive Link Power Management allows SATA devices to enter a low power state during periods of inactivity to save power. It is supported only by AHCI mode.


Configuration options: [Enabled] [Disabled]

Hard Disk S.M.A.R.T.

S.M.A.R.T stands for Self-Monitoring, Analysis, and Reporting Technology. It is a monitoring system for computer hard disk drives to detect and report on various indicators of reliability.

Configuration options: [Enabled] [Disabled]

5.3.4 Super IO Configuration



COM1 Configuration

Use this to set parameters of COM1.

Type Select

Use this to select COM1 port type: [RS232], [RS422] or [RS485].

Speed Selection

Use this option to select the COM1 speed: [Normal Speed] or [High Speed].


When High Speed is selected and the required driver is installed, COM1 can support a baud rate of 921600.

WDT Timeout Reset

Use this to set the Watch Dog Timer.

Configuration options: [Enabled] [Disabled]

5.3.5 ACPI Configuration



Suspend to RAM

Suspend to RAM allows you to select [Disabled] for ACPI suspend type S1. It is recommended to select [Auto] for ACPI S3 power saving.

Configuration options: [Auto] [Disabled]

Onboard LAN Power On

Use this item to enable or disable onboard LAN to turn on the system from the power-soft-off mode.


Configuration options: [Enabled] [Disabled]

RTC Alarm Power On

RTC Alarm Power On allows the system to be waked up by the real time clock alarm. Set it to By OS to let it be handled by your operating system.

Configuration options: [Enabled] [Disabled] [By OS]

5.3.6 USB Configuration




USB Power Control

Use this option to control USB power.

Configuration options: [Always Enabled] [Default Setting]

5.3.7 Power Configuration



OCP Function

Enabled to set adapter over current protect.

5.3.8 Trusted Computing



NOTE: Options vary depending on the version of your connected TPM module.

Security Device Support

Security Device Support allows you to enable or disable BIOS support for security device. O.S. will not show Security Device. TCG EFI protocol and INT1A interface will not be available.

Configuration options: [Enabled] [Disabled]

Active PCR banks

This item displays active PCR Banks.

Available PCR Banks

This item displays available PCR Banks.

SHA256 PCR Bank

SHA256 PCR Bank allows you to enable or disable SHA256 PCR Bank.

Configuration options: [Enabled] [Disabled]

SHA384 PCR Bank

The item allows you to enable or disable SHA384 PCR Bank.

Configuration options: [Enabled] [Disabled]

Pending Operation

Pending Operation allows you to schedule an Operation for the Security Device.

NOTE: Your computer will reboot during restart in order to change State of the Device.

Configuration options: [None] [TPM Clear]

Platform Hierarchy

This item allows you to enable or disable Platform Hierarchy.

Configuration options: [Enabled] [Disabled]

Storage Hierarchy

This item allows you to enable or disable Storage Hierarchy.

Configuration options: [Enabled] [Disabled]

Endorsement Hierarchy

This item allows you to enable or disable Endorsement Hierarchy.

Configuration options: [Enabled] [Disabled]

Physical Presence Spec Version

Select this item to tell OS to support PPI spec version 1.2 or 1.3. Please note that some HCK tests might not support version 1.3.

Configuration options: [1.2] [1.3]

TPM 2.0 InterfaceType

This item allows you to view the Communication Interface to TPM 2.0 Device: CRB or ITS.

Device Select

This item allows you to select the TPM device to be supported.

[TPM 1.2] restricts support to TPM 1.2 devices.

[TPM 2.0] restricts support to TPM 2.0 devices.

[Auto] supports both TPM 1.2 and TPM 2.0 devices with the default set to TPM 2.0 devices. If TPM 2.0 devices are not found, TPM 1.2 devices will be enumerated.


Onboard TPM

The option enables or disables Intel PTT in ME. Disable this option to use discrete TPM Module.

Configuration options: [Enabled] [Disabled]

5.4 Hardware Health Event Monitoring Screen

This section allows you to monitor the status of the hardware on your system, including the parameters of the CPU temperature, motherboard temperature, fan speed, and the critical voltage.



NOTE: Options vary depending on the features of your motherboard.

Fan1 Setting

This allows you to set FAN1's speed. The default value is [System Auto].

Configuration options: [System Auto] [Full On] [Automatic Mode].

Case Open Feature


This item allows you to enable or disable case open detection feature. The default is value [Disabled].

Clear Status

This option appears only when the case open has been detected. Use this option to keep or clear the record of previous chassis intrusion status.

5.5 Security Screen

In this section you may set or change the supervisor/user password for the system. You may also clear the user password.



Supervisor Password

Set or change the password for the administrator account. Only the administrator has the authority to change the settings in the UEFI Setup Utility. Leave it blank and press enter to remove the password.

User Password


Set or change the password for the user account. Users are unable to change the settings in the UEFI Setup Utility. Leave it blank and press enter to remove the password.

Secure Boot

Press [Enter] to configure the Secure Boot Settings. The feature protects the system from unauthorized access and malwares during POST.

5.6 Boot Screen

This section displays the available devices on your system for you to configure the boot settings and the boot priority.



Boot From Onboard LAN

The item allows the system to be waked up by the onboard LAN.

Configuration options: [Enabled] [Disabled]

Setup Prompt Timeout

The item allows you to configures the number of seconds to wait for the UEFI setup utility.

Configuration options: [1] - [65535]

Bootup Num-Lock

The item allows you to select whether Num Lock should be turned on or off when the system boots up.

Configuration options: [On] [Off]

Full Screen Logo

[Enabled] Select this item to display the boot logo.

[Disabled] Select this item to show normal POST messages.

5.7 Exit Screen



Save Changes and Exit

When you select this option, the following message “Save configuration changes and exit setup?” will pop out. Select [Yes] to save the changes and exit the UEFI SETUP UTILITY.

Discard Changes and Exit

When you select this option, the following message “Discard changes and exit setup?” will pop out. Select [Yes] to exit the UEFI SETUP UTILITY without saving any changes.

Discard Changes

When you select this option, the following message “Discard changes?” will pop out. Select [Yes] to discard all the changes.

Load UEFI Defaults

The item allows you to load UEFI default values for all options. The F9 key can be used for this operation.

Launch EFI Shell from filesystem device

The item allows you to copy shellx64.efi to the root directory to launch EFI Shell.

Chapter 6 Software Support

6.1 Install Operating System

This motherboard supports various Microsoft® Windows® operating systems: 10 64-bit / 11 64-bit. Because motherboard settings and hardware options vary, use the setup procedures in this chapter for general reference only. Refer your OS documentation for more information.