



P/N: 15G065144000AK V1.0

Quick Installation Guide

1U12XL-EPYC/2T2E / 1U12XL-EPYC/2T



1U12XL-EPYC/2T2E




1U12XL-EPYC/2T


Cable List

No.	Item
A	SMBus Y Cable, MB to BPB
B	MINISAS HD Cables, RB to BPB (3.5" HDD)
C	MINISAS HD Cables, MB to BPB (3.5" HDD)
D	MiniSAS HD to 4 SATA Cable, RB to BPB (2.5" HDD) (1U12XL-EPYC/2T only)
E	Oculink x4 to Slimline x4 Cables, MB to BPB (2.5" HDD) (1U12XL-EPYC/2T2E only)
F	Power Cable, ATX 20Pin, MB to PDB
G	PMBus Cable, MB to PDB
H	Power Cable, 8Pin CPU Power, MB to PDB
I	Power Y-Cable, PDB to BPB (1U12XL-EPYC/2T2E only)
J	Power Y-Cable, PDB to BPB (1U12XL-EPYC/2T only)
K	Display Cable, MB to FPB
L	USB 3.0 Cable, MB to Server (Front Panel)


MiniSAS HD Cables / SMBus Y Cable Connection




MiniSAS HD Cables Connection (1U12XL-EPYC/2T only)



OcuLink Cable Connection (1U12XL-EPYC/2T2E only)



Power Cables / PMBus Cable Connection



Display Cable / Front Panel Board / USB Cable Connection

